



NX100 TRANSMITTER

PRE-INSTALLATION MANUAL

Document: NHB-NX100-PRE

Issue: 3.2 2017-03-31

Status: Standard

Nautel Limited

10089 Peggy's Cove Road
Hackett's Cove, NS Canada B3Z 3J4
Phone: +1.902.823.3900 or
Toll Free: +1.877.6NAUTEL (6628835) (Canada & USA only)
Fax: +1.902.823.3183

Nautel Inc.

201 Target Industrial Circle
Bangor, Maine USA 04401
Phone: +1.207.947.8200
Fax: +1.207.947.3693

Customer Service (24 hour support)

+1.877.628.8353 (Canada & USA only)
+1.902.823.5100 (International)

Email: support@nautel.com

Web: www.nautel.com

The comparisons and other information provided in this document have been prepared in good faith based on publicly available information. The reader is encouraged to consult the respective manufacturer's most recent published data for verification.

© Copyright 2017 NAUTEL. All rights reserved.

CONTENTS

RELEASE CONTROL RECORD	IX
------------------------	----

ABOUT THIS MANUAL	XI
-------------------	----

ABOUT SAFETY	XV
Electrical Hazards	xv
Lightning Hazards	xvi
RF Hazards	xvi
Toxic Hazards	xvi
Other Hazards	xvi

SAFETY PRECAUTIONS	XVII
Personal Safety	xvii
Site Safety	xviii
Equipment Safety	xx

DECLARATION OF CONFORMITY	XXIII
---------------------------	-------

DESCRIPTION	1-1
Capabilities	1-1
Options	1-3

PRE-INSTALLATION TASKS	2-1
Preparing for installation	2-1
Selecting a location for the transmitter	2-3
Installing an antenna feedline	2-3

PHYSICAL REQUIREMENTS	3-1
Dimensions	3-1
Clearances	3-2
Weight	3-9
<hr/>	
COOLING REQUIREMENTS	4-1
Air flow in the transmitter	4-1
Cooling	4-3
Heating	4-8
<hr/>	
ELECTRICAL REQUIREMENTS	5-1
Electrical power	5-1
Station reference ground	5-9
<hr/>	
RF OUTPUT REQUIREMENTS	6-1
RF output connector	6-1
Antenna feed cable	6-1
Antenna system	6-4
<hr/>	
PLANNING AUDIO INPUTS	7-1
Analog inputs	7-1
Digital inputs	7-2
Other considerations	7-3

PLANNING CONTROL/MONITOR CONNECTIONS	8-1
AUI control (local and remote)	8-1
External system interlock	8-2
External PDM inhibit	8-4
Remote inputs	8-5
Remote outputs	8-9
Analog outputs	8-12
Web based control	8-13

PARTS AND TOOLS	9-1
Contacting Nautel	9-1
Parts supplied by Nautel	9-1
Parts not supplied by Nautel	9-2
Parts ordering	9-2
Module replacement program	9-2
Tools for installation	9-3

PRE-INSTALLATION ASSISTANCE	10-1
Pre-installation consulting	10-1
Installation and commissioning service	10-1
Online documentation	10-2
On-site support	10-3
Training	10-3
Extended warranties	10-4

LIST OF TERMS	11-1
----------------------	-------------

RELEASE CONTROL RECORD

Issue	Date	Reason
3.0	2012-11-01	Release 3 of product (NARA52B)
3.1	2016-02-08	<p>Section 1: Description: added SNMP and Phone Home options to Remote Control and Monitoring section.</p> <p>Section 5: Electrical Requirements: added NOTE below Table 5.1 to specify line current operating conditions and inrush current rating.</p> <p>Section 7, Planning Audio Inputs: added stereo broadcast NOTE to “AES/EBU” paragraph; added DRM Simulcast paragraph to “Other Considerations” sub-section.</p> <p>Section 8: Planning Control/Monitor Connections: added more detail to Web Based Control section, including SNMP, Nautel Phone Home, etc.</p>
3.2	2017-03-31	<p>Section 3: Updates to cabinet required Clearances</p> <p>Section 4: Updates to Cooling Requirements, Table 4.1 and 4.2.</p> <p>Section 5: Updates to Primary Ac Wiring based on transformer voltage, Table 5.1 through Table 5.3.</p> <p>Section 8: Added Factory Default settings for Remote I/O, Table 8.2 and Table 8.4</p>

ABOUT THIS MANUAL

This manual provides information about preparing for the delivery and installation of an NX100 transmitter. This manual is intended for use by field technicians, site managers, and installation planners.

USING THIS MANUAL

Read the task list provided in [Section 2, “Pre-installation tasks” on page 2-1](#). The task list describes the preparations you must make prior to receiving and installing the NX100 transmitter.

Later sections of the manual provide reference information regarding physical, cooling, electrical, and antenna requirements.

TECHNICAL SUPPORT

Nautel offers technical support to customers over the Internet and by telephone. Nautel’s customer support team will answer your questions and work with you to identify and resolve problems.

For 24-hour technical support, call toll free at 1.877.628.8353 (in USA and Canada only) or call 1.902.823.5100 (international) or find us on the Internet at <http://www.nautel.com>.

For parts and tools information, see [“Parts and tools” on page 9-1](#) of the *NX100 Pre-Installation Manual*.

For extended warranty information, see [“Pre-installation assistance” on page 10-1](#) of the *NX100 Pre-Installation Manual*.

NX100 TRANSMITTER MANUALS

The NX100 documentation suite includes the following documents:

NX100 PRE-INSTALLATION MANUAL, NX100-PREINST. Provides instructions and reference information needed when planning and preparing for the installation of an NX100 transmitter.

NAUTEL SITE PROTECTION MANUAL. Provides detailed information about protecting your site from lightning-related hazards.

NX100 INSTALLATION MANUAL, NX100-INST. Provides instructions and reference information needed when installing an NX100 transmitter.

NX100 OPERATING AND MAINTENANCE MANUAL, NX100-OPS-MAINT. Provides instructions for operating, maintaining and troubleshooting an NX100 transmitter. It also provides reference information needed when performing diagnostic procedures.

NX100 TROUBLESHOOTING MANUAL, NX100-TROUBLE. Provides detailed technical information about the NX100 transmitter, including electrical schematics and mechanical drawings.

NAUTEL WEBSITE / ONLINE RESOURCES

The Nautel website provides useful resources to keep you up to date on your NX100.

NAUTEL USER GROUP (NUG)

The website includes a special section that customers can log into in order to access the Nautel customer newsletter, product manuals, frequently asked questions (FAQ), information sheets, quick guides and information about field upgrades.

Figure 3.1: Accessing the NUG



DOCUMENTATION: ONLINE AND PRINTED

The website’s NUG section provides online access to all the documentation for your NX100. Documentation is provided in Acrobat (PDF) format. You can use the documentation online or print the sections that you need.

When using online documents:

- Click on the blue hyperlinks to jump to a related section, or to get additional information (e.g., view a term’s definition).
- To search a document to find keywords, use **Find** in Acrobat Reader’s **Edit** menu.
- To quickly find a specific section, click the section in the PDF file’s **Bookmarks** list.

When using printed documents:

- To find keywords, go to the *Index* section at the end of the manual.
- To find a specific term, go to the *List of Terms* section near the end of the manual.

ABOUT SAFETY

All Nautel transmitters are designed to meet the requirements of EN60215, Safety Requirements for Radio Transmitters. The philosophy of EN60215 is that the removal of any cover or panel that can only be opened using a tool is a maintenance activity, and that any person performing a maintenance activity is expected to be trained for that activity. Under EN60215, it is assumed that trained personnel will be knowledgeable and will take precautions such as removing all power to the transmitter before accessing its components.

ELECTRICAL HAZARDS

To remove power from the transmitter, switch off and lock out the ac power. There are three amber LEDs at the bottom rear of the cabinet that glow to remind anyone who has not turned off the power that the system is live and serious danger is present.

DANGER - HIGH VOLTAGE



Indicates dangerous voltage (in excess of 72 volts), capable of causing a fatal electrical shock, are present on or near parts bearing this label.

WARNING: IT IS NOT ENOUGH TO SWITCH OFF RF POWER. THE POWER LINE IS STILL CONNECTED. DISCONNECT AND LOCK OUT THE UPSTREAM SUPPLY BEFORE SERVICING.

Mount the transmitter ac power disconnect switch/breaker close to the transmitter so that it can be reached quickly in an emergency. Clearly label the switch/breaker (e.g., **EMERGENCY SWITCH**).

After turning off the power, always perform a measurement to confirm that the power is off before touching anything within the transmitter. If the wrong breaker was opened, the equipment will be live.

WARNING: DO NOT USE AN ORDINARY MULTIMETER TO CHECK FOR VOLTAGE, SINCE IT MAY HAVE BEEN LEFT INADVERTENTLY ON THE AMP (A) RANGE, TRIGGERING A SHORT AND AN ARC BLAST THAT COULD RESULT IN SEVERE BURNS AND EVEN DEATH.

Use only a non-contact voltage probe or a safety voltmeter (available from vendors such as Fluke, Ideal, and Teagam).

Use a proper lockout procedure to ensure that another worker cannot accidentally reapply power while you are performing maintenance on any part of the transmitter or site.

LIGHTNING HAZARDS

Before opening the transmitter and touching internal parts, remove and solidly ground the antenna connection.

WARNING: IT IS NOT ENOUGH TO GROUND THE ANTENNA TERMINAL WITH THE ANTENNA STILL CONNECTED. EVEN A SMALL IMPEDANCE IN THE GROUND STRAP WILL RESULT IN LETHAL VOLTAGES DURING A LIGHTNING STRIKE.

RF HAZARDS

A serious RF hazard and very high voltages exist in the vicinity of the antenna and its networks during normal operations.

TOXIC HAZARDS

There may be devices used in this equipment that contain beryllium oxide ceramic, which is non-hazardous during normal device operation and under normal device failure conditions. These devices are specifically identified with “(BeO)” in the Description column of the Troubleshooting Manual’s parts list(s).

Do not cut, crush or grind devices because the resulting dust may be hazardous if inhaled. Unserviceable devices should be disposed of as harmful waste.

OTHER HAZARDS

Ensure that appropriate fire alarms and fire extinguishers are available. Extinguishers must be suitable for use on electrical fires.

Many other site safety risks exist. It is beyond the scope of this manual to identify all the risks and procedures.

SAFETY PRECAUTIONS

This section provides very important information about protecting the safety of personnel and equipment:

- [Personal Safety](#) - see page xvii
- [Site Safety](#) - see page xviii
- [Equipment Safety](#) - see page xx

PERSONAL SAFETY

TRAINING

The training of any personnel who will have physical access to the site or the transmitter is very important. Personnel must be familiar with the transmitter, so that they can avoid physical danger, and be aware of hazards to themselves and the equipment.

Nautel offers a number of training courses covering the basic fundamentals of RF systems and transmitters, and the operation and maintenance of the transmitter. For more information about available courses and schedules, go to the Nautel website at <http://www.nautel.com/Training.aspx>, or ask your Nautel sales representative.

SITE ORIENTATION

When you give personnel access to the transmitter site (e.g., hiring new personnel, or giving access keys to personnel), perform a site orientation to ensure that they are familiar with the site, on-site procedures, and on-site hazards. Cover the following topics:

- Securing the site (locking doors and fences) to prevent unauthorized access
- How and when to call for technical support or emergency assistance
- Areas of the site and pieces of equipment that are off limits

VOLTAGE AWARENESS

Ensure that all personnel that are able to access areas with high voltage circuits or high field strengths are aware of the hazards associated with high voltage. Cover the following topics:

- High voltage or high field strength areas where caution is required
- Physical risks of electric shock
- Risks for personnel with pacemakers or other medical implants
- Induced voltages in high field strength areas
- On-site risks during thunderstorms and lightning strikes
- Operation of safety interlocks (if installed)

FIRST AID

Nautel does not offer first aid training, since the hazards associated with high voltage and RF energy are not specific to the transmitter. However, the customer should provide first aid training to all personnel who have access to the transmitter site. First aid training should include CPR, care of burns, artificial respiration, and defibrillation if specific equipment is available on-site.

SITE SAFETY

CONTROLLING ACCESS

Transmitters and antennas generate and carry dangerous voltages that can be harmful or fatal. It is very important that you control access to the site and its equipment. To secure your transmitter site, use:

- Locking steel or security doors to prevent casual access
- A perimeter fence to keep trespassers away from the antenna system and feedline
- “No Trespassing” signs
- An alarm system

MARKING HAZARDS

Place warning signs close to any hazardous areas or systems (e.g., the feedline or the antenna system). Make the signs large enough that they cannot be missed. Provide signage in all languages used in the region. These signs are intended not only for authorized personnel, but also for emergency responders or accidental trespassers.

QUALIFYING SITE PERSONNEL

Make sure that personnel who have access to the site are qualified to work around electronics and high voltage systems.

AC POWER PROTECTION

You should take steps to protect equipment from surges (over-voltage spikes) on the ac power lines. Surges may occur during thunderstorms, or because of malfunctions in the electrical distribution grid. Surge suppressors and ac power conditioners can prevent serious damage to your on-site equipment, including the transmitter.

RF PROTECTION

Transmitters and their antenna systems create intense radio frequency fields at the transmitter site, particularly near the feedline, antenna and tower. At some sites, these fields may cause biological effects, including the heating of body tissues. Intense fields can also create dangerous high voltages on ungrounded, conductive surfaces and objects. At certain points where high voltage conductors come close to grounded conductors (e.g., at feedline junctions or on the tower), dangerous electrical arcing or overs can occur. It is very important that you take the following steps to prevent damage to equipment or personnel due to RF fields:

- Use safety interlocks to de-energize transmitters if personnel open doors or panels accessing high field areas
- Place warning signs in any locations where high fields can occur
- Train personnel about the short-term and long-term hazards of RF radiation
- Use personal RF monitors to alert personnel when hazardous RF radiation levels are present
- Physically block access to the area around the antenna system, feedline and tower
- Ground all exposed conductive surfaces or objects in high field areas

The RF connection to the transmitter output can be a serious safety hazard. Connect a 50 Ω test load during installation and commissioning. It is recommended that a switch be used to automatically connect the transmitter to the antenna system without human contact with the transmitting conductors.

SAFETY INTERLOCKS

The transmitter contains an electrical interlock, which is an external circuit that turns off the RF output if any of its switches are opened.

AC DISCONNECT SWITCH

Safe operation of the transmitter requires an ac disconnect switch. Lock the ac disconnect switch in the disconnected (open) position during the installation process.

EQUIPMENT SAFETY

ELECTROSTATIC PROTECTION

The transmitter's systems are very rugged and resistant to damage. However, it is possible for damage to occur because of high voltage electrostatic discharges during servicing. Train all service personnel to ground themselves to bleed off any static charge before opening the transmitter or touching any exposed components. Provide a grounding wand or known ground (e.g., a grounded metal table) that personnel can use to discharge themselves.

SURGE PROTECTION

Surge protection is recommended for your entire site. However, even if you do not use a surge protector on the service entrance to the site, you should install a surge protector in the transmitter's ac power feed to prevent over-voltage from entering the transmitter.

LIGHTNING PROTECTION

The transmitter is designed to resist lightning strike damage. However, intense or repeated strikes could damage the transmitter. We recommend that you install lightning suppression on the antenna, tower and feedline to reduce the effect of lightning strikes on the transmitter itself (and to protect the rest of your site equipment and your personnel). For detailed information about lightning protection, see the Nautel Site Preparation Manual, available from your Nautel sales agent, or online from the Nautel website.

PHYSICAL PROTECTION

Consider physical hazards to equipment at your site, including the transmitter. Ensure that equipment is protected from weather (e.g., rain or flooding), even during extreme weather events. Place equipment so that it is not in the path of swinging doors or high-traffic areas. Do not allow wheeled items like office chairs or tables with wheels in the transmitter room, as these may damage equipment if accidentally pushed or knocked over. Do not place the transmitter under water pipes, drains, or sprinklers. Keep any equipment that generates heat, like the transmitter, away from flammable materials like ceiling panels, cubicle dividers, and curtains.

EARTHQUAKE PROTECTION

If the transmitter site is in a region that experiences any noticeable earthquake activity, take steps to prevent the transmitter from shifting or rocking during an earthquake. Even during minor earthquakes, rocking or movement of the transmitter is likely to damage the feedline connection, and could even cause a catastrophic failure of the ac power feed into the transmitter. During larger earthquakes, the weight of the transmitter chassis could be hazardous to nearby equipment or personnel.

DECLARATION OF CONFORMITY

Hereby, Nautel Ltd. declares that this MF Broadcast Transmitter NX100 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The subject equipment is intended for use in the following Member States (identified by ISO 3166 2-letter code):

AT	BE	CY	CZ
DK	EE	FI	FR
DE	GR	HU	IE
IT	LV	LT	LU
MT	NL	PL	PT
SK	SI	ES	SE
GB	IS	LI	NO
CH	BG	RO	TR

The use of this equipment requires a license in the above listed Member States.

The original Declaration of Conformity may be found on the Nautel Web site:

www.nautel.com

CE0168 

SECTION 1: DESCRIPTION

This section provides a basic description of the NX100 transmitter and includes the following topics:

- [Capabilities](#)
- [Options - see page 1-3](#)

CAPABILITIES

POWER

The NX100 is capable (with 120% positive peak modulation) of up to 110 kW of RF carrier power. The maximum continuous average power (carrier plus modulation) is 150 kW (corresponding to 100 kW of carrier power with 100% continuous tone modulation) the NX100 is capable of operating indefinitely at this power level.

The operator can vary the power continuously or switch to preset power levels using the NX100 graphic user interface (AUI). The power output can also be scheduled to correspond with authorized daytime power levels.

MODULATION

The NX100 is capable of double sideband (AM) modulation. With the addition of an optional internal signal generator, IBOC modulation can be provided to the exciter. DRM modulation can be provided to the exciter with an external modulator that produces I/Q over AES.

ANTENNA TOLERANCE

The NX100 will operate at rated power with a VSWR of up to 1.5:1. A higher VSWR results in a protective reduction of output power. The greater the VSWR, the greater the reduction in RF power. (To maintain the quality of digital broadcasts, lower VSWR levels are required. Consult with Nautel.)

The NX100 will not fail or completely shut down, regardless of antenna or feedline failure.

REMOTE CONTROL AND MONITORING

The NX100 has several remote control and monitoring options that allow you to monitor critical parameters of transmitter operation and control common functions, such as power output and exciter selection.

- AUI - logging into the remote AUI (advanced user interface) via a LAN connection to the transmitter.
- SNMP - configurable through the remote AUI; allows configuration of agents and traps.
- Discrete Wiring - routing multiconductor signaling cable from the transmitter to a remote control board.
- Nautel Phone Home - configurable through the remote AUI; monitors transmitter data and allows Nautel's Customer Service Department to proactively support your transmitter, possibly before a fault occurs.

REDUNDANCY

The NX100 features redundancy in all key systems:

- RF power modules
- Power supplies
- Exciters
- Cooling fans
- Low voltage power supplies

AC POWER

The NX100 variable power transformer can be set to use a range of input voltages and power frequencies, as described in [Section 5, "Electrical requirements"](#) on page 5-1 of this manual.

OPTIONS

RF OUTPUT

The NX100 supports the use of a 3-1/8 inch EIA female connector (standard) or optionally, a 4-1/16 inch EIA female connector. The appropriate inner male (bullet) connector and flange connector to complete the RF output connection are not provided with the transmitter and must be purchased separately.

IBOC

The NX100 supports IBOC digital radio as a modulation option. The external IBOC signal source provides a signal to the NX100 exciter. See [“IBOC” on page 7-2](#) for more information.

DRM

The NX100 supports Digital Radio Mondiale (DRM) radio as a modulation option. The external DRM signal source provides a modulating signal to the NX100 exciter via I/Q over AES. See [“DRM” on page 7-2](#) for more information.

OPEN/CLOSED AIR COOLING

There are two cooling configurations available for the transmitter. See [Section 4, “Cooling requirements” on page 4-1](#) for more information.

GPS SYNC CARD

A GPS sync PWB can be purchased that is capable of driving a 3.3 V or 5 V GPS antenna. If the optional GPS sync PWB is installed, it provides the necessary 10 MHz, 1 PPS and 1 kHz sync signals used by the exciter(s). The exciter uses these signals to synchronize the transmitter’s carrier frequency and phase to this GPS reference. See [“Frequency synchronization signals” on page 7-3](#) for more information.

USB SOUND CARD

The NX100 supports using audio files stored on a USB flash drive as a backup audio source. The USB sound card is necessary for connecting the audio output of the single-board computer (SBC) to the exciter’s audio input.

SPARES

A kit of spare parts is available that contains fuses, ferrite toroids, semiconductors, low voltage power supplies, cooling fan, air filter and other items. Additional spare parts and assemblies may be purchased individually including RF power modules, fan tray assemblies and PWB assemblies.

SECTION 2: PRE-INSTALLATION TASKS

This section provides a list of tasks that you must perform prior to delivery and installation of the NX100 transmitter.



WARNING: FAILURE TO COMPLY WITH RECOMMENDATIONS MAY VOID YOUR MANUFACTURER'S WARRANTY. FOR MORE INFORMATION, REVIEW YOUR WARRANTY DOCUMENTS.

PREPARING FOR INSTALLATION

To prepare for installation of an NX100 transmitter, perform the following tasks:

1. Ensure that the correct transmitter configuration is ordered. Check the ac power requirements, preset frequency and selected options.
2. Select a location for the transmitter in the transmitter room. Determine whether additional heating, ventilating or cooling capacity is needed at the site. Identify any special requirements regarding air flow around the cabinet (for example, ducting hot air away from the cabinet, or bringing in external cooling air). See [“Selecting a location for the transmitter” on page 2-3](#).
3. If this is an upgrade or replacement transmitter (that is, if the site is already set up for a transmitter), go to [Step 7](#). (If you are upgrading a site, verify the feedline, the lightning protection systems, and the ac power service. Refer to Nautel's *Recommendations for Transmitter Site Preparation Manual*.)
4. Install ac power service into the planned location of the transmitter, and select a location for the ac power entrance cabinet near the transmitter location. For detailed information, see [“Electrical power” on page 5-1](#).

Be aware of lightning protection issues when installing ac power. Lightning protection is essential to protect both personnel and equipment at your site. Refer to Nautel's *Recommendations for Transmitter Site Preparation Manual*.

5. Install lightning protection on the antenna tower. Refer to Nautel's *Recommendations for Transmitter Site Preparation Manual*.
6. Place a work area with a clear table surface near the transmitter location. Provide electrostatic protection measures in the work area.

7. Order any accessories or optional equipment that you may need.
8. Terminate the transmitter end of the RF feedline with the appropriate mating connector. Unless otherwise specified in contract documents, the transmitter will accept a 3-1/8 inch EIA flange connector.
9. If the transmitter will be used to broadcast IBOC or DRM, perform a full impedance sweep of the antenna system. See [“Antenna system” on page 6-4](#).
10. Arrange manpower or lifting equipment to move and assemble the transmitter. You may want to use a forklift to move either the transmitter or its power transformer into place for installation.
11. Implement a safety interlock, if required. See the *NX100 Operations and Maintenance Manual* for details on using the optional keyed interlock system.
12. If you are going to use an external frequency reference, ensure that the reference source meets required specifications.
13. Prepare to integrate the NX100 transmitter into your station control circuitry, if required.
14. Train your station technicians and operators on the use and maintenance of the NX100 transmitter.

SELECTING A LOCATION FOR THE TRANSMITTER

To ensure that the desired location for the NX100 transmitter is suitable, perform the following tasks:

1. Ensure that the floor area where the transmitter will be located is able to support the weight of the transmitter system.
 2. Measure the space to ensure that the transmitter will fit. See [Section 3, “Physical requirements”](#) for transmitter dimensions and clearances.
 3. Ensure that transmitter room doors and the pathway of access from the receiving dock or building exterior to the installation location are large enough to accommodate the transmitter.
-

INSTALLING AN ANTENNA FEEDLINE

When installing an antenna feedline for the NX100 transmitter, perform the following tasks:

1. Ensure that the RF feedline that will connect the transmitter and the antenna system has a suitably rated coaxial cable.
2. Connect the shield of the antenna feedline coaxial cable directly to the station reference ground where it enters the building. For more information about the station reference ground, see [“Station reference ground” on page 5-9](#).
3. Install lightning protection devices. For more information about lightning protection, refer to Nautel’s *Recommendations for Transmitter Site Preparation Manual*.
4. Pass the center conductor and the shield of the feedline cable through a ferrite toroid that is positioned between the shield ground at the building entrance and the shield termination at the transmitter. Install the ferrite toroid prior to installing flanges on the feedline cable.
 - To obtain the proper size ferrite toroid, contact Nautel support for recommendations (see [page 10-3](#)), or consult additional, outside suppliers.

SECTION 3: PHYSICAL REQUIREMENTS

This section provides physical specifications for the NX100 transmitter and its components, and lists physical site requirements. This section includes the following topics:


- [Dimensions](#)
- [Clearances - see page 3-2](#)
- [Weight - see page 3-9](#)

DIMENSIONS

The NX100 main transmitter (excluding power transformer cabinet and ac power entrance) has the following dimensions:

- Height: 184.0 cm (72.4 in)
- Width: 95.7 cm (37.7 in)
- Depth: 118.1 cm (46.5 in)

Figure 3.1: NX100 transmitter



External power transformer cabinet
not shown (see Figure 3.6)

CLEARANCES

For the main transmitter cabinet, allow the following clearances:

- Front and Rear: 1.2 m (4.0 feet) required minimum to allow for the front and rear door swing.
- Left Side (as viewed from front): 0.9 m (3.0 feet) required minimum for possible combiner maintenance (the combiner pipe is 3 feet long and may need to be removed from this side).
- Right Side (as viewed from front): 0.6 m (2.0 feet) recommended minimum for possible combiner maintenance. Allow enough room for someone to comfortably work at the side of the transmitter for possible maintenance activities such as removing the side panel, replacing a fuse, removing combiner pipe hardware, etc.

Check the clearance to ensure that you will be able to open all doors and access panels. The front control panel is hinged on the left (as viewed from the front of the transmitter).

Also consider access to the rear of the transmitter during installation and servicing, and access to the front of the transmitter during power module replacement. You must allow space to open the front panel and slide out any of the power modules. These modules slide straight in and out of the shelf unit in the front of the transmitter.

Figure 3.2: NX100 top view




Figure 3.3: NX100 top view (with door swing)




Figure 3.4: NX100 front view




Figure 3.5: NX100 side and rear views






Figure 3.6: NX100 External Power Transformer Cabinet



Note: Dimensions are based on the standard 380 V transformer primary voltage. Size may vary based on the primary voltage; contact Nautel for custom primary voltage options.

Figure 3.7: Ac power entrance



WEIGHT

See [Table 3.1](#) for the various weights of transmitter components, including crated and uncrated weights.

Table 3.1: Weight of components

CRATE CONTENTS	UNCRATED WEIGHT	CRATED WEIGHT
Main transmitter cabinet (with modules)	567 kg (1250 lbs)	687 kg (1515 lbs)
Power transformer cabinet	753 kg (1659 lbs)	835 kg (1840 lbs)
Ac power disconnect switch	TBD kg (TBD lbs)	TBD kg (TBD lbs)

Note: Power transformer cabinet and ac power disconnect switch weights are based on the standard 380 V transformer primary voltage. Weight may vary based on the primary voltage; contact Nautel for custom primary voltage options.

SECTION 4: COOLING REQUIREMENTS

This section provides information about heating and cooling requirements for the NX100 transmitter site. Topics in this section include:

- [Air flow in the transmitter](#)
- [Cooling - see page 4-3](#)
- [Heating - see page 4-8](#)


AIR FLOW IN THE TRANSMITTER

There are two configurations for drawing cooling air through the NX100 - open air cooling and closed air cooling. The NX100 has redundant cooling fans to aid each configuration in ensuring effective cooling.

OPEN AIR CONFIGURATION

In an open air configuration (see [Figure 4.1](#)), cooling air is drawn through air filters in the back of the transmitter. Air circulates down into the base of the transmitter, and is then pushed up through the front of the transmitter by a set of fans. Warm air exits the transmitter through the grill at the top. Exhaust air may or may not be ducted away from the transmitter. Cool air for the intake cannot be ducted to the transmitter as this would block access to the rear of the transmitter.

Figure 4.1: Air flow in the NX100 transmitter (open air cooling shown)




CLOSED AIR CONFIGURATION

In a closed air configuration (see [Figure 4.2](#)), cool air is drawn in through a grill or duct at the top of the transmitter, near the back. The air circulates inside the transmitter and exhausts in the same manner as the open air cooling option. In this configuration, cooling air must be ducted to the intake grill and the exhaust air must be ducted away from the transmitter.

Closed air cooling requires an optional panel (Nautel Part # 207-8211) to cover the filter cut-out in the rear door. This panel is available from Nautel.

Figure 4.2: Air Flow in the NX100 Transmitter (closed air cooling shown)



COOLING

Do not allow the transmitter room ambient air temperature to exceed 50°C (122°F) at sea level. Cooler temperatures are recommended in order to improve the reliability of the transmitter. At higher altitudes, derate the maximum inlet air temperature as follows:

- De-rate the ambient temperature 3°C (5.4°F) per 500 m – or 2°C (3.6°F) per 1,000 feet – above sea level.

Example: At 1600 m (1 mile) above sea level, maximum ambient temperature should not exceed 40.4°C (104.7°F).

Note: Ensure hot air from the transmitter is not drawn back into the transmitter's cool air intake.

COOLING PLANT REQUIREMENTS

In an NX100 system, heat is generated by both the transmitter and the transformer, and each may be cooled separately. The transmitter's efficiency is typically 92% and the transformer's efficiency is 98%. Calculate the power dissipated by the transmitter using the following equation:

$$P_{\text{loss (XMTR)}} = \left(\frac{1}{\eta_{\text{XMTR}}} - 1 \right) \bar{P}_{\text{out}}$$

Where η_{XMTR} is the transmitter's efficiency and \bar{P}_{out} is the transmitter's average output power. Calculate the power dissipated by the power transformer using the following equation:

$$P_{\text{loss (XFMR)}} = \left(\frac{1}{\eta_{\text{XFMR}}} - 1 \right) \frac{\bar{P}_{\text{out}}}{\eta_{\text{XMTR}}}$$

Where η_{XFMR} is the transformer's efficiency. For continuous tone modulation, calculate the average output power of the transmitter using the following equation:

$$\bar{P}_{\text{out}} = \left(1 + \frac{m^2}{2} \right) P_c$$

Where m is the modulation depth and P_c is the transmitter's output carrier power.

Table 4.1 and Table 4.2 show the cooling requirements for the transmitter and power transformer, respectively, when operating with various continuous tone modulation levels. To determine the number of British thermal units (Btu) being generated per hour as waste heat, multiply the waste heat (in watts) by 3.413. To determine the air conditioning (in tonnes), multiply the waste heat (in watts) by 0.000285.

Table 4.1: Cooling Requirements for the NX100

CARRIER POWER OUT (kW)	MODULATION DEPTH (M x100)	AVERAGE POWER OUT (kW)	WASTE HEAT (kW)	WASTE HEAT (BTU/HOUR)	AIR CONDITIONING REQUIRED IN A CLOSED SYSTEM (TONNES)
100	100%	150	13.3	45,507	3.8
100	75%	128.1	11.4	38,870	3.2
100	50%	112.5	10	34,130	2.9

Table 4.2: Cooling Requirements for the Power Transformer

CARRIER POWER OUT (kW)	MODULATION DEPTH (M x100)	AVERAGE POWER OUT (kW)	WASTE HEAT (kW)	WASTE HEAT (BTU/HOUR)	AIR CONDITIONING REQUIRED IN A CLOSED SYSTEM (TONNES)
100	100%	150	3.3	11,377	1.0
100	75%	128.1	2.8	9,718	0.8
100	50%	112.5	2.5	8,533	0.7

Note: Although normal program audio is generally equivalent to 50-75% continuous tone modulation, Nautel recommends you design the cooling system for 100% continuous tone modulation, to allow sufficient overhead and for testing purposes.

CLOSED LOOP OR FORCED AIR COOLING SYSTEMS

INTAKE REQUIREMENTS. Closed loop or forced air cooling systems can be used, so long as the air is well filtered to prevent dust and insects from entering the transmitter, and so long as a minimum of 1,500 cubic feet per minute (CFM) at 0.5 pounds per square inch (PSI) is supplied to the intake duct.

EXHAUST REQUIREMENTS. 1,500 cubic feet per minute (CFM) .

Note: To ensure specified operation, the transmitter's fans cannot drive any extra back-pressure. Therefore, Nautel recommends that the exhaust duct system include exhaust fans.



CAUTION: The cooling system's evaporator may have a maximum air temperature capability [typically 35°C (95°F)]. If so, note that the maximum temperature rise from the transmitter's intake to exhaust is 20°C.

Nautel recommends you leave a gap between the top of the transmitter and the bottom of the exhaust hood, as shown in [Figure 4.3](#).

Figure 4.3: Gap for Exhaust Air



This gap will serve two purposes:

1. For air conditioned closed loop systems, the maximum air temperature into the evaporator may be limited to 35°C (95°F). By ensuring an adequate gap (as shown), the fan for the evaporator can be selected to draw more air than the rack will exhaust, allowing room air to mix with the warmer exhaust air from the transmitter, thus reducing the evaporator's intake temperature.
2. If the cooling system's exhaust fan fails or the exhaust duct is blocked, the transmitter is still able to exhaust into the room.

COOLING SYSTEM CONFIGURATION

Especially in warmer climates, Nautel recommends an air conditioned cooling system with ducted exhaust and free-air return. A split system air conditioner can be cost effective, provided the distance between the evaporator and condenser can be kept to a minimum. This configuration also minimizes dust and sand buildup within the equipment. An example of this type of system is shown in Figure 4.4, which shows a combined NX400, 800 kW transmitter system with each transmitter having a dedicated split system air conditioner, with a third split system air conditioner used to cool the heat load in the room from various sources (e.g., power transformers, combiner losses, solar, other equipment, etc.).

Figure 4.5 on page 4-7 shows a diagram of a split system air conditioner system, as well as examples of indoor an outdoor unit components.

Figure 4.4: Air Conditioned Cooling System (combined 800 kW system shown)






Figure 4.5: Split System Air Conditioner Examples



TRANSFORMER COOLING CONFIGURATION

The transmitter's mains transformer is contained in an external cabinet and must also be cooled. If the transformer cabinet is located in the same room as the transmitter, you can include the transformer's heat losses with the room heat load. If the power transformer cabinet is located in a separate room, it is not necessary to use an air conditioner to cool it; it can be cooled by exchanging the air in the room, as shown in [Figure 4.6](#).

Figure 4.6: Forced ventilation of the power transformer cabinet



Forced ventilation of the power transformer is necessary for ambient temperatures greater than 20°C (68°F), or in small, poorly ventilated rooms. The fan can be thermostat-controlled and can operate as an extractor in the top part of the room. Calculate the recommended air flow (S') using:

$$S' \text{ [at } 20^{\circ}\text{C (68}^{\circ}\text{F)}] = 0.1 \times P \text{ m}^3/\text{s}$$

Where P is the transformer's waste heat (in kW, see [Table 4.2 on page 4-4](#)). Convert this to a CFM value by multiplying the result by 2119.

HEATING

The transmitter room must contain a heating system that will ensure the ambient air temperature does not drop below 0°C (32°F).

SECTION 5: ELECTRICAL REQUIREMENTS

This section describes electrical power and electrical protection requirements associated with the NX100 transmitter. This section includes the following topics:

- [Electrical power](#)
- [Station reference ground - see page 5-9](#)



CAUTION: Technical pre-commissioning activities described in this section require technical decisions and the customization of electrical circuits. Do not attempt to perform these activities unless you are a certified electrician.

Refer to *Nautel's Recommendations for Transmitter Site Preparation Manual* for information about requirements associated with lightning protection.

ELECTRICAL POWER

The transmitter is preconfigured to operate from a 50/60 Hz 3-phase, 3-wire plus ground, Wye or closed delta ac power source. You select the specific voltage range when you order the transmitter.

VOLTAGE STABILITY

The ac power source nominal voltage must be stable to within plus or minus 15% under all loading conditions. The transmitter contains circuitry that maintains the RF output at the preset carrier level for voltage variations within the specified range, provided the correct transformer tap is chosen.

POWER CONSUMPTION

When operating at 100 kW with 100% modulation by a continuous sine wave, power consumption is approximately 167 kW (171 kVA). When operating at 100 kW with no modulation, power consumption is 111 kW. Power consumption for a specific station will depend on the programming format and the level of audio processing. Nautel recommends the ac power source have a 25% over-capacity to ensure adequate regulation.

PRIMARY AC WIRING

When operating at 100 kW with 100% modulation by a continuous sine wave, line currents are approximately as shown in [Table 5.1](#) through [Table 5.3 on page 5-2](#). Use this information to determine appropriate wire and breaker sizes for the ac input. **NOTE:** Primary wiring is provided by the end user.

Table 5.1: Approximate Line Currents for 600 V Transformer (580 V ac - 620 V ac)

AC INPUT VOLTAGE (V)	LINE CURRENT (A)
620	191.6
600	198.0
580	204.8

Table 5.2: Approximate Line Currents for 480 V Transformer (440 V ac - 520 V ac)

AC INPUT VOLTAGE (V)	LINE CURRENT (A)
520	228.5
500	237.6
480	247.5
460	258.3
440	270.0

Table 5.3: Approximate Line Currents for 380 V Transformer (340 V ac - 440 V ac)

AC INPUT VOLTAGE (V)	LINE CURRENT (A)
440	270.0
420	282.8
400	297.0
380	312.6
360	330.0
340	349.4

NOTE: Line currents shown are based on operation at nameplate power, 100% continuous modulation and 10% low ac line. Ac wiring must also be rated to handle inrush current (12 x line current) for 0.1 s.

RECOMMENDED CONFIGURATION. Use a 4-wire Wye (star) configuration, with the three phases balanced to ground.



CAUTION:

Do NOT use open delta three-phase ac power sources that use two identical transformers. These systems are susceptible to third harmonic distortion and line transients, and may cause peak voltages to exceed the line voltage. This can cause increased power supply noise or even component failure (for example, rectifier failure).

AC POWER SWITCH

Install an external ac power disconnect between the ac power source and the transmitter's transformer. (Nautel can provide a suitable ac power disconnect, if required.) For safety, place the ac disconnect close to the transmitter and label it **TRANSMITTER EMERGENCY ON/OFF SWITCH**.

AC TRANSIENT POWER PROTECTION

Protect all conductors from the ac power source by connecting bi-directional surge protection devices between each conductor and the station reference ground. In addition, pass all the conductors and ground, as a group, through a ferrite toroid. Install a ferrite toroid (Nautel Part # LX63, located in the ancillary kit) on the ac feed between the transmitter and the bi-directional surge protector.)

A surge protector panel containing suitably rated varistors is available from Nautel. Install the surge protector panel close to the station reference ground, and as close as possible to the ac service entrance.

The ac power source usually has the lowest impedance path to ground during a lightning strike and normally carries most of the lightning-induced current away from the transmitter site. When lightning hits the power source (for example, striking a transmission line near the transmitter site), a significant induced current may flow towards the transmitter. The goal of lightning protection is to route the current around the transmitter to the best available ground.

For detailed information about surge protectors and lightning protection, refer to Nautel's *Recommendations for Transmitter Site Preparation Manual*.


SECONDARY AC WIRING

The following information pertains to the wiring, cable connectors and cable tray support system, between the external power transformer cabinet and the main transmitter cabinets.

Note:
*It is highly recommended that you purchase suitable wiring, hardware and cable trays from Nautel. If you decide to purchase these items from an alternate vendor, it is imperative that you read and understand the information presented in this section, as it provides specific part information as well as insight into some of Nautel's design philosophy behind the interconnect wiring requirements. **Do not use the provided secondary wiring in place of primary wiring.***

OVERVIEW. See Figure 5.1. The NX100 transmitter requires a 3-phase, 400 V ac source, capable of providing 171 kVA. The transmitter consists of a main cabinet (rack) and an external power transformer. The transformer's secondary supplies three-phase ac power (4-wire: X1, X2, X3, X0) to the main cabinet. A single-point ground connection is required between the transformer cabinet and the transmitter's station reference ground, located on top of the main cabinet. This ac power is applied to a 3-phase rectifier assembly in the main cabinet.

Figure 5.1: Transformer to Transmitter Interconnect Wiring



Additionally, the main cabinet contains a single-phase 2 kW logic supply that receives its ac input from one of the three phases and X0.

WARNING: DO NOT CONNECT THE X0 TERMINAL OF THE POWER TRANSFORMER TO GROUND. BLOWN FUSES AND POSSIBLE DAMAGE TO THE 3-PHASE SCR MAY RESULT.


WIRE TYPE. For the three-phase secondary connections, a 535 MCM, tray rated diesel wire is required [available from Nautel, Part # WT04, Vendor (Anixter Inc.) # 5N-5351-F14].

This wire has been selected for various reasons, including:

- 535 MCM correctly rated for the rectifier's ac current requirements, considering bundling of three wires and temperature rating [50°C (122°F)]
- compatible with Cytelok cable connectors (see [“Cable connectors” on page 5-6](#))
- FT4 rated (for flame resistance) for use with cable trays (see [“Cable tray” on page 5-7](#))
- flexible, high-strand, allowing easy bend radius for drops from tray into transmitter racks

For the neutral and ground connections, you require a 1/0 AWG, tray rated wire [available from Nautel, Part # WT02 (black, X0) and Part # WT01 (green, ground)]. 1/0 AWG is the smallest allowable tray-rated wire diameter so the neutral wire size is determined by its FT4 rating rather than ampacity.

Wire lengths are dependent on the distance between the transformer cabinet and main transmitter cabinet. All wiring can be purchased as part of Nautel's Cable Tray Parts Kit (Nautel Part # 207-8385-08). In some cases, a custom cable tray is designed to meet a site's specific requirements. If so, refer to the associated NX system documentation for details on the cable tray assembly.

Figure 5.2: Cytolok Cable Connectors

CABLE CONNECTORS. See [Figure 5.2](#). For all interconnecting wiring between the transformer cabinet and transmitter cabinet, Nautel uses a spring compression cable connector called Cytolok [Nautel Part # JA93 (535 MCM wires) and Nautel Part # JA92 (1/0 AWG wires)].

These cable connectors offer various advantages over other connector types, including:

- no compression (crimp) tool required
- no Belleville washers required
- easy to install
- field proven reliability
- 500/600 MCM connector is compatible with 535 MCM multi-strand cable

Cytolok connectors are provided by Nautel in an ancillary kit. Refer to the *NX100 Installation Manual* for details on terminating wires in the Cytoloks.

CABLE TRAY. See Figure 5.3. For all interconnecting wiring between the transformer cabinet and transmitter cabinet, Nautel recommends (and can provide) a cable tray support system (Nautel Part # 207-8385-08, see [Table 5.4 on page 5-8](#)). Other options include armoured cable such as Teck90 or conduit.

The advantages of using a cable tray system are:

- established, approved, reliable method to route high-current wiring
- easily accommodates top entry into transmitter cabinets (cable tray is suspended from ceiling) and supports wire weight
- fuse assembly on side of transformer cabinet pre-fitted to accept 4" x 18" cable tray; each transmitter cabinet pre-fitted to accept 4" x 6" cable tray

Cable tray lengths are dependent on the distance between the transformer cabinet and transmitter cabinets. All cable tray parts can be purchased as part of Nautel's Cable Tray Parts Kit (Nautel Part # 207-8385-08). Refer to Figure 5.3 of this manual and to the *NX100 Installation Manual* for details on installing the cable tray.

Plan your cable tray installation to ensure its position does not interfere with any exhaust ducting being used see [Section 3, "Physical requirements"](#).

Table 5.4: Cable Tray Parts Kit (Nautel # 207-8385-08)

DESCRIPTION	QTY	NAUTEL PART #	VENDOR #
Cable Tray Ladder, Alum, 6"W x 4"D x 120"L	2	HCT23	LCA43-06-12
Tyrap, .190W x 14.5Lg, WeatherResist., Black	30	HT59	PLT4S-MO
Cable Tray elbow 90 Deg, 6" Vert Outside	2	HCT26	LCA43-6-12-V090-R12
Cable Tray Coupling, 4" Deep	4	HCT20	LCA43-C
Wire 1/0 Tray Rated, 90C, 600V, Green	30 ft.	WT01	3BALU-1011-04 AIW
Wire 1/0 Tray Rated, 90C, 600V, Black	30 ft.	WT02	3BALU-1011-02 AIW
Wire, Diesel, 535 mcm, FT4 Tray Rated	90 ft.	WT04	5N-5351
Cable Tray, Trapeze Hanger, 6"	3	HCT27	LCA43-6-TH
Threaded Rod, M12 x 1.75, 2m lg, Zn plated steel	6	HCT29	867-038ZP
Cable Cleat Kit	7	207-8373	-
Bolt, Hex, M8 x 1.25 x 30 lg	16	HMBH03	-
Washer, Plain, M8	32	HMW06	-
Washer, Split, M8	16	HMW14	-
Nut, Hex, M12 x 1.75	30	HMN08	-
Washer, Plain, M12, SS	30	HMW08	-
Washer, Split, M12, SS	20	HMW16	-

NOTES:

- All parts prefixed by Nautel Part # HCT are from vendor Canadian Electrical Raceways.
- All parts prefixed by Nautel Part # WT are from vendor Anixter Inc.
- ** - denotes wire length is customer specific.

STATION REFERENCE GROUND

See [Figure 5.1](#). Install a station reference ground that provides a continuous, low impedance path to the earth.


Connect the transmitter cabinet's designated safety ground point, the shield of the coaxial feedline, and the ground connection of the power source directly to the surge protector, using a 10 cm (4 in.) copper strap. Connect the surge protector to the station reference ground using a copper strap that is at least 10 cm (4 inches) wide.

Ac power enters the transmitter cabinet through the right side of the top panel (see [Figure 3.2 on page 3-4](#)).

Ensure that the transmitter site's grounding rods are adequate. For more information about electrical grounding protection, see Nautel's *Recommendations for Transmitter Site Preparation Manual*.

* - Install Cable Cleat Kit every 1 m along horizontal rungs

** - Denotes item is cut to length on site



ITEM #	QTY	NAUTEL #	VENDOR #	DESCRIPTION
1	2	HCT23	LCA43-06-12	Cable Tray Ladder, Alum, 6"W x4"D x120"LG
2	30	HT59	PLT4S-MO	Tyrap
3	2	HCT26	LCA43-6-12-VO90-R12	Cable Tray elbow 90deg, 6" vert outside
4	4	HCT20	LCA43-C	Cable Tray Coupling, 4' D
5	30 ft	WT01	3BALU-1011004	Wire, I/O, Tray Rate, 90C, 600V, Green
6	30 ft	WT02	3BALU-1011-02	Wire, I/O, Tray Rate, 90C, 600V, Black
7	90 ft	WT04	5N-5351	Wire, Diesel, 535MCM, FT4, Tray Rated, OD=1.2", 2kV
8	3	HCT27	LCA43-6-TH	Cable Tray, Trapeze Hanger, 6"
9	6	HCT29	867-038ZP	Threaded Rod, M12 x 1.75 2m LG, Zinc-plated steel
10	7	207-8373	207-8373	Cable Cleat Kit
01	16	HMBH03	-	Bolt, Hex, M8 x 1.25 x 30LG
02	32	HMW06	-	Washer, Plain, M8
03	16	HMW14	-	Washer, Split, M8
04	30	HMN08	-	Nut, Hex, M12 x 1.75
05	30	HMW08	-	Washer, Plain, M12
06	20	HMW16	-	Washer, Split, M12

Figure 5-3: NX100 Standard Cable Tray System

SECTION 6: RF OUTPUT REQUIREMENTS

This section describes requirements associated with the antenna and RF cabling to be used with the NX100 transmitter. Antenna considerations include the following:

- [RF output connector](#)
- [Antenna feed cable](#)
- [Antenna system - see page 6-4](#)

For detailed information about protecting the antenna system from lightning strikes, see the *Nautel Site Protection Manual*.

RF OUTPUT CONNECTOR

See “[RF Output](#)” on [page 1-3](#) for the connector configuration options for the transmitter.

ANTENNA FEED CABLE

MAXIMUM VOLTAGE

The maximum voltage at the transmitter’s connection to a 50 Ω load is 8,700 V peak, when operating at 100 kW, with peak modulation, at a VSWR of 1.5:1.

HIGH VOLTAGE FEED THROUGH

Be very careful whenever a high voltage RF conductor passes through a wall or bulkhead. Gas insulation flashovers can occur in poor installations. Ensure that this part of your installation is installed by professionals experienced with high-power radio frequency circuits.

INSULATOR FLASHOVER. Surface flashovers along an insulator occur when there is an electrical breakdown in the gas (normally air) at its surface. The mechanism that triggers a flashover depends on the insulation surface conditions. Gas breakdown flashover occurs when one or more of the following conditions are met:

- The voltage field at the insulator surface or at an adjacent electrode reaches the critical breakdown level for the gas.
- The electrode or insulator interface is poor or dirty, resulting in a three material junction. This creates excessive high voltage stress on the air insulator, causing a gas breakdown flashover.
- Moisture damage on the insulator surface creates regions of high voltage that can cause a gas breakdown flashover.

THREE-MATERIAL JUNCTIONS: A frequent cause of breakdowns at an insulator surface is the junction of three materials: a metal conductor, a solid insulator, and a gas insulator. The insulators form a capacitive RF divider between the metal conductor and the grounded periphery. Since the dielectric constant of the solid is higher than the gas (air), the high voltage stress is concentrated on the air.

It is very important to minimize the junction's stress gradient and to avoid triple junctions wherever possible.



WARNING: FAILURE TO PROVIDE CORRECT STRESS CONTROL AT HIGH RF VOLTAGE CONDUCTOR/INSULATOR JUNCTIONS CAN CAUSE INSULATOR BREAKDOWNS OR EVEN FIRES.

BOWL TYPE BUSHINGS. Use bowl type bushing insulators to increase the surface tracking distance from the central conductor to the grounded periphery or wall.

INSULATOR BREAKDOWN/DAMAGE. An insulator can be damaged during gas breakdown flashovers. When current flows across the surface of an insulator, especially when it is coated with a conductive contaminant that is slightly damp, carbon tracks can form. Once this occurs, the track provides a conductive path and reduces the effectiveness of the insulator.

Pitting and erosion of the insulator may also occur. To reduce the possibility of tracking damage, clean all insulator surfaces periodically, and use stress control techniques at the conductor/insulator junction.

OTHER CAUSES. Other causes of breakdowns may include improperly adjusted spark balls or the disruption of air gaps by rain, snow, insects, birds, grass, or an accumulation of pollution (soot) on insulator surfaces.

SMALL RADIUS CONDUCTORS

Be careful when using small radius conductors to carry high RF voltages and currents. If the radius is too small it may cause a local corona, which can lead to a breakdown.

FEEDLINE TESTING

Test the RF transmission system from the transmitter flange to the antenna before putting the transmitter into service. This is very important, especially if you are re-using an existing site with a previously installed feedline. Ensure that the entire system can tolerate the expected peak voltages of normal operation, especially those occurring during modulation peaks, without breaking down.

ANTENNA SYSTEM

Ensure that the antenna system meets or exceeds the standards specified in EIA Standard TR-101-A, paragraph 8(b) (see below for the specific requirement), with a normal impedance of 50 ohms at the carrier frequency.

- The impedance (resistance and reactance) characteristics of the normal load shall be such that when the operating carrier frequency changes by ± 5 kHz, the resistance will be within 5% of the resistance at the carrier frequency, and the reactance (adjusted to zero at the carrier frequency), will be within $\pm 18\%$ of the resistance at the carrier frequency. When the carrier frequency changes by ± 10 kHz, the corresponding limits of permissible variation for resistance and reactance are 10% and 35% respectively.

The transmitter will operate with a maximum VSWR of 1.5:1, or with sideband VSWRs of up to 2:1 when the carrier frequency impedance is 50 ohms. However, overall system performance degrades as the VSWR increases.

Advances in digital modulation schemes like IBOC and DRM systems require better performance from antenna systems. To ensure the proper operation during digital broadcasting, ensure that the VSWR does not exceed the values recommended by each standard.

In order to achieve the proper sideband symmetry (Hermitian symmetry) needed for IBOC or DRM operation, you may need to adjust the tuning of the antenna system to balance the impedances at the sidebands. You must perform a full impedance sweep of the antenna system before broadcasting IBOC or DRM. This also requires information about the transmitter's phase versus frequency characteristic for Hermitian symmetry at the power amplifier. This information is provided with the transmitter at time of shipment. For assistance relating to IBOC or DRM transmitter requirements, contact Nautel Customer Support.



Note:

Hermitian symmetry may not be required for DRM if the VSWR across the bandwidth of the transmitted signal is very low. Contact Nautel for recommendations.

SECTION 7: PLANNING AUDIO INPUTS

The NX100 supports all current forms of AM broadcasting. This section describes the requirements associated with the audio feeds to the transmitter.

- [Analog inputs](#)
 - [Balanced \(mono\)](#)
 - [AES/EBU](#)
- [Digital inputs - see page 7-2](#)
 - [IBOC - see page 7-2](#)
 - [DRM - see page 7-2](#)
- [Other considerations - see page 7-3](#)
 - [Frequency synchronization signals - see page 7-3](#)
 - [Audio Player via USB - see page 7-3](#)
 - [DRM Simulcast - see page 7-3](#)

ANALOG INPUTS

The transmitter does not have extensive audio processing capabilities. Use an external audio processor to ensure that the audio source material is processed properly. An audio processor will adjust the dynamic range, loudness, frequency response and symmetry parameters to suit the transmission system. Carefully control the peak levels.

For monaural applications, the audio may be processed to provide up to 135% positive peak program modulation, with a 100 kW RF carrier at the nominal ac voltage.

Refer to the Operating section of the *NX100 Operations and Maintenance Manual* for an example of setting an analog preset.

The NX100 accepts the following analog inputs:

BALANCED (MONO)

Modulating audio must be applied from an external source to **BALANCED ANALOG AUDIO XLR** connector J12 on the control/interface PWB (A11A1). The audio source must be balanced, able to drive a 600 Ω load, and produce a level between -10 and +12 dBm for 100% modulation.

Only one analog input is provided. Program content from the input is applied to both exciters.

AES/EBU

AES/EBU must be applied from an external source to **ANALOG AES/EBU** XLR connector J10 or J11 on the control/interface PWB (A11A1). The external source must produce a level between -30 and 0 dBFS for 100% modulation.

NOTE: Stereo broadcast is only possible by using one of the AES/EBU inputs.

DIGITAL INPUTS

The NX100 accepts the following digital inputs:

IBOC

To use an IBOC (In Band On Channel) input, the NX100 requires the optional engine PWB (A11A7). The engine PWB accepts the digital audio data from an Importer/Exporter arrangement via a LAN (local area network) connection and, in conjunction with the control/interface PWB (A11A1), provides the LVDS signals (I and Q) to the exciter in CMOS format.

The digital audio data from the LAN/Exporter must be connected via an Ethernet cable to **ETHERNET** connector J1 on the engine PWB. The transmitter's GUI allows configuration of the IBOC input.

Refer to the Importer and Exporter documentation for more information.

Refer to the Operating section of the *NX100 Operations and Maintenance Manual* for an example of setting an IBOC preset.

DRM

To use a DRM (Digital Radio Mondiale) input, the NX100 requires an external DRM modulator module. The DRM exciter module accepts the digital audio data via a LAN connection and provides the baseband I and Q signals to **AES/EBU** connector J10 on the control/interface PWB (A11A1), in AES/EBU format.

Refer to the DRM exciter module's documentation for more information.

Refer to the Operating section of the *NX100 Operations and Maintenance Manual* for an example of setting a DRM preset.

OTHER CONSIDERATIONS

FREQUENCY SYNCHRONIZATION SIGNALS

You can apply a 10 MHz synchronization signal from an external source or using the optional GPS sync PWB, which can be installed in the transmitter.

OPTIONAL GPS SYNC PWB

A GPS sync PWB can be purchased that is capable of driving a 3.3 V or 5 V GPS antenna. If the optional GPS sync PWB is installed, it provides the necessary 10 MHz, 1 PPS and 1 kHz sync signals used by the exciter(s). The exciter uses these signals to synchronize the transmitter to this GPS reference. The GPS sync PWB connects to dual D-sub connector J5 of the control/interface PWB.

EXTERNALLY SOURCED

If you are using an externally generated 10 MHz signal (such as a GPS clock signal) for use as the reference frequency for the RF drive (carrier frequency), connect it to the **10 MHz SYNC** BNC connector J8 on the control/interface PWB. The external 10 MHz frequency reference must:

- remain stable at 10 MHz within ± 20 Hz
- have a peak-to-peak amplitude of between 2.2 V and 8.0 V (sine wave or square wave)
- be spectrally pure, since spurs may pass through to the transmitter output.

AUDIO PLAYER VIA USB


There is provision to configure the transmitter's audio player feature to use an external USB device connected to a USB port on the single-board computer (SBC). The files on the USB device (e.g., mp3 files) will act as the audio playlist. Refer to the *Operations and Maintenance Manual* for details on using the Audio Player's Playlist feature, available through the AUI.

DRM SIMULCAST

For broadcasting in DRM simulcast, Nautel recommends applying the analog modulation input directly to one of the transmitter's audio inputs, in addition to the digital I/Q over AES stream being applied to one of the transmitter's AES inputs from the DRM modulator. This allows the transmitter to effectively manage its own power control and protection, as it normally would.

NOTE: Do not connect the analog modulation source to a DRM modulator and apply a combined analog and DRM signal to the transmitter. If the analog is combined with the DRM carriers by the DRM modulator and applied to the transmitter as a single combined I/Q over AES stream, some of the normal transmitter protections will not function properly.

Figure 7.1: Audio Connections



SECTION 8: PLANNING CONTROL/MONITOR CONNECTIONS

This section describes the types of control and monitoring for the NX100 transmitter. Consider this information and plan for the necessary requirements (wiring, remote switches/indicators, LAN, etc.):

- [AUI control \(local and remote\)](#)
- [External system interlock - see page 8-2](#)
- [External PDM inhibit - see page 8-4](#)
- [Remote inputs - see page 8-5](#)
- [Remote outputs - see page 8-9](#)
- [Analog outputs - see page 8-12](#)
- [Web based control - see page 8-13](#)
- [SNMP Control/Monitoring - see page 8-14](#)
- [Nautel Phone Home - see page 8-15](#)

AUI CONTROL (LOCAL AND REMOTE)

The NX100's front door contains an advanced user interface (AUI) that allows you to locally control all transmitter functions and set parameters and schedules.

The remote AUI allows you to adjust any parameter and view any status available in the local AUI via a web browser on a computer connected to the LAN connector on the single-board computer's motherboard (A1U1) on the back of the control cabinet's front door.

The NX100 also allows control and monitoring through an Ethernet connection via SNMP, supporting version 1 of the protocol, with traps.

The local or remote AUI also allow you to configure the remote inputs to control various transmitter functions and monitor the transmitter's status by means of a conventional, parallel wire remote control interface (see [“External system interlock”](#) and [“Remote outputs”](#) on page 8-9) or an Ethernet connection (see [“Web based control”](#) on page 8-13).

For detailed information about the AUI, refer to the *NX100 Operating and Maintenance Manual*.

EXTERNAL SYSTEM INTERLOCK

You can connect an external system interlock to terminal block TB1 (terminals 1 through 4) of the control/interface PWB (A11A1), located on the exciter panel behind the front door. This connection allows you to configure an external system interlock circuit for the NX100. This circuit can be configured as single-ended or differential, using user-provided shorting jumpers on terminal block TB1 (see [Figure 8.1 on page 8-3](#)).

SINGLE ENDED INPUT (INTERNAL DC SUPPLY). If you are using the transmitter's 15 V as the current source for the system interlock circuit, install a shorting jumper between the **+15V** terminal (TB1-1) and the **+** terminal (TB1-2) and connect your system interlock circuit between the **GND** terminal (TB1-4) and the **-** terminal (TB1-3).


The system interlock circuit must present a short circuit (low impedance) between TB1-4 and TB1-3 when the interlock circuit is intact and it is safe to enable the RF output. It must present an open circuit when any external interlock switch is activated and the RF output requires inhibition.

DIFFERENTIAL INPUT (EXTERNAL DC SUPPLY). If you are using an external dc supply (capable of providing between 12 V and 25 V) as the current source for the system interlock circuit, connect the supply's positive output to the **+** terminal (TB1-2) and the supply's ground (negative) output to the **-** terminal (TB1-3), via the system interlock circuit. No shorting jumper is required.

The system interlock circuit must present a short circuit (low impedance) between the external supply's ground (negative) output and TB1-3 when the interlock circuit is intact and it is safe to enable the RF output. It must present an open circuit when any external interlock switch is activated and the RF output requires inhibition.

You can install any number of serial interlock switches provided the above conditions are met. If you are not using an external system interlock circuit, connect user-provided jumpers between TB1-1 and TB1-2 and between TB1-3 and TB1-4.

Figure 8.1: External Interlock and PDM Inhibit Circuits



EXTERNAL PDM INHIBIT

You can connect an external PDM inhibit to terminal block TB1 (terminals 5 through 8) of the control/interface PWB (A11A1), located on the exciter panel behind the front door. This connection allows you to configure an external PDM inhibit circuit that provides an emergency RF inhibit control for the NX100. This circuit can be configured as single-ended or differential, using user-provided shorting jumpers on terminal block TB1 (see [Figure 8.1](#)).

SINGLE ENDED INPUT (INTERNAL DC SUPPLY). If you are using the transmitter's 15 V as the current source for the PDM inhibit circuit, install a shorting jumper between the **+15V** terminal (TB1-5) and the **+** terminal (TB1-6) and connect your external PDM inhibit circuit between the **GND** terminal (TB1-8) and the **-** terminal (TB1-7).

The external PDM inhibit circuit must present a short circuit (low impedance) between TB1-8 and TB1-7 when the RF output requires inhibition. It must present an open circuit for normal operation.

DIFFERENTIAL INPUT (EXTERNAL DC SUPPLY). If you are using an external dc supply (capable of providing between 12 V and 25 V) as the current source for the external PDM inhibit circuit, connect the supply's positive output to the **+** terminal (TB1-6) and the supply's ground (negative) output to the **-** terminal (TB1-7), via the external PDM inhibit circuit. No shorting jumper is required.

The external PDM inhibit circuit must present a short circuit (low impedance) between TB1-8 and TB1-7 when the RF output requires inhibition. It must present an open circuit for normal operation.

REMOTE INPUTS

You can connect to up to 16 remote inputs, which allow you to remotely control various operational characteristics of the transmitter. Each input is mapped to a control that is user defined. See [Table 8.1 on page 8-5](#) for a list of input options and their functional descriptions. See [Table 8.2 on page 8-6](#) for the associated input terminals and control switches (see “[Backup control switches](#)” on page 8-8) on the remote interface PWB (A11A4). Refer to the *NX100 Operations and Maintenance Manual* for instructions on changing the remote input settings, including which setting is assigned to the input pin and which logic is required to change (activate, enable, etc.) the setting.

Unless otherwise noted these inputs are only accepted by the transmitter if the remote/local status is set to remote. That setting can only be made by a local user using the front panel AUI.

The external remote input circuits interface with the transmitter via the remote interface PWB and then with opto couplers on the control/interface PWB. The opto couplers buffer and isolate the external circuits and prevent any unwanted transients from affecting transmitter operation while remote control is selected on the transmitter.

Table 8.1: Remote Inputs - Selection Options

Remote Input	Function
RF On	Same as pressing the AUI RF On button. Tells the transmitter to provide RF power if possible. Provide an active pulse to select.
RF Off	Same as pressing the AUI RF Off button. Tells the transmitter to disable RF power. Provide an active pulse to select.
Reset	Causes a system reset. Provide an active pulse to select.
Increase RF Power	Increases the power level of the current mode. Send an active pulse to increase the power slightly, or send a signal of greater duration to continue increasing power.
Decrease RF Power	Decreases the power level of the current mode. Send an active pulse to decrease the power slightly, or send a signal of greater duration to continue decreasing power.
Exciter A Select	Causes a changeover to select exciter A as the active exciter. Provide an active pulse to select.
Exciter B Select	Causes a changeover to select exciter B as the active exciter. Provide an active pulse to select.
Auto Changeover	Enables or disables automatic exciter changeover. Provide an active pulse to toggle between selecting automatic or manual.
Scheduler On/Off	Enables or disables the automatic mode scheduler. Provide an active pulse to toggle between selecting automatic or manual.
Max Power Lockout Select	Selects the associated power lockout limit (1 to 8) as active. Provide an active pulse to select.
Preset Select	Selects the associated user-named mode as the active preset. Provide an active pulse to select.

Table 8.2: Remote Inputs - Remote Interface PWB Circuits

Remote Input	Input Terminal	Switch	Factory Default Channel	Factory Default Control
1	J7-8	01	RF On/Off	Falling Edge, Turn On
2	J7-7	02	RF On/Off	Falling Edge, Turn Off
3	J7-6	03	Reset	Falling Edge, Reset
4	J7-4	04	Inc / Dec Rf Power	Falling Edge, Increase
5	J7-3	05	Inc / Dec Rf Power	Falling Edge, Decrease
6	J7-2	06	Main Exciter	Falling Edge, Set to A
7	J8-8	07	Main Exciter	Falling Edge, Set to B
8	J8-7	08	Auto Changeover	Falling Edge, Toggle
9	J8-6	09	Not Assigned	-
10	J8-4	10	Not Assigned	-
11	J8-3	11	Not Assigned	-
12	J9-8	12	Not Assigned	-
13	J9-7	13	Not Assigned	-
14	J9-6	14	Not Assigned	-
15	J9-4	15	Scheduler On/Off	Falling Edge, Toggle
16	J9-3	16	Not Assigned	-


EXTERNAL SWITCHING CIRCUIT REQUIREMENTS

The switching circuits for the remotely controlled functions must be the equivalent of a normally open (momentary) switch. The switches must be configured to operate as a single-ended input using the transmitter's 15 V dc as the source, or as a differential input using an external dc power supply (12 - 18 V) applied to J6-7 or J6-8. The control/interface PWB contains a selection circuit that allows you to select internal (single-ended, see Option 1) or external (differential, see Option 2) dc power supply for all remote inputs.

Inputs are toggled between states by an active pulse unless otherwise noted. To ensure proper operation, the duration of the active pulse should be a minimum of 250 ms. Refer to the *NX100 Operations and Maintenance Manual* to see the various logic control options for remote inputs.

OPTION 1 - SINGLE ENDED INPUT (INTERNAL DC SUPPLY). When you use the transmitter's 15 V as the current source for a control function's opto coupler, configure the circuits on the control/interface PWB for single ended inputs (see [Figure 8.2](#)). The INT/EXT 3-pin header (E3) must have its 2-socket shunt post connected between pins 2 and 3 to configure the circuit.


Figure 8.2: Single-Ended Input Selected



When the remote input is configured for logic '0', a negative logic (current-sink-to-ground) command must be applied to the appropriate remote input (1 through 16). To avoid a ground loop, obtain the ground from the remote interface PWB (J7-1 or 5, J8-1 or 5, or J9-1 or 5).

OPTION 2 - DIFFERENTIAL INPUT (EXTERNAL DC SUPPLY). When you use an external dc voltage (12 V to 18 V) as the current source for a control function's opto coupler, configure the control function's external switching circuit and the control/interface PWB's selection circuit for a differential input (see [Figure 8.3 on page 8-8](#)). The INT/EXT 3-pin header (E3) must have its 2-socket shunt post connected between pins 1 and 2 to configure the circuit.

Figure 8.3: Differential Input Selected



The normally open/momentarily closed switch should be located between the dc supply's negative output and the remote input.

BACKUP CONTROL SWITCHES

The remote interface PWB contains a push-button switch [01 (S1) through 16 (S16)] for each of the 16 remote inputs. Each switch provides a means to locally activate its associated remote input in the event that the associated AUI control is not available. See [Table 8.2 on page 8-6](#) to determine the switch associated with each of the remote inputs.

Below each switch is a blank, white label to allow for labelling of the control.

REMOTE INPUT CONNECTIONS

Remote inputs 1 through 16, as required, connect to the terminals of connectors J7, J8 and J9 on the remote interface PWB (A11A4). See [Table 8.2 on page 8-6](#) to determine the input terminal associated with each remote input.

REMOTE OUTPUTS

Up to 16 remote outputs, that indicate either the presence of various alarms or the status of operator controlled circuits, are available for remote monitoring on connectors J3, J4 and J5 on the remote interface PWB (A11A4). The sources and active logic levels of these remote outputs are user-defined. See [Table 8.3 on page 8-10](#) for a list of output options and their descriptions. See [Table 8.4 on page 8-11](#) for the associated output terminals and status LEDs (see “LED configuration”) on the remote interface PWB.

A switching device for each remote output provides the desired active logic when a true condition exists. Nautel presets all remote outputs for Logic ‘0’ Active.

If the remote output is configured as Logic ‘0’ Active (see the *NX100 Operations and Maintenance Manual*), then the remote output’s switching circuit will provide a current-sink-to-ground when a logic true condition exists and an open collector for a logic false condition.

If the remote output is configured as Logic ‘1’ Active (see the *NX100 Operations and Maintenance Manual*), then the remote output’s switching circuit will provide an open collector when a logic true condition exists and a current-sink-to-ground for a logic false condition.

LED CONFIGURATION

The remote interface PWB contains a bi-colour LED (DS1 through DS16) and a shorting jumper (E1 through E16) for each of the 16 remote outputs. Each LED can be configured to glow green for a status output or red for an alarm output, by setting the position of the associated shorting jumper. For a status output, install the shorting jumper to short positions 1 and 2 of its post. For an alarm output, install the shorting jumper to short positions 2 and 3 of its post. See [Table 8.4 on page 8-11](#) to determine the LED and shorting jumper associated with each remote output.

Below each LED is a blank, white label to allow for labelling of the status/alarm output.

REMOTE OUTPUT CONNECTIONS

Remote outputs 1 through 16, as required, connect to terminals of connectors J3, J4 and J5 on the remote interface PWB (A11A4). See [Table 8.4 on page 8-11](#) to determine the output terminal associated with each remote output.

Table 8.3: Remote Outputs - Selection Options

Remote Output	Description
Remote Enabled Status	Indicates the local/remote control status of the transmitter. Logic true if transmitter is in remote mode. Logic false if transmitter is in local mode. Changes can only be made remotely if the transmitter is set to remote mode. The local user's control of transmitter operation is limited, unless the transmitter is set to local mode.
RF On/Off Status	Indicates the on/off status of the transmitter's RF power stage. Logic true if RF is enabled.
Active Exciter Status	Indicates which exciter is presently active. Logic true if exciter A is active. Logic false if exciter B is active.
Auto Changeover Status	Indicates the status of the auto changeover function. Logic true if enabled (auto). Logic false if disabled (manual).
Main Exciter Status	Indicates which exciter is selected as main. Logic true if exciter A is main. Logic false if exciter B is main.
Scheduler On/Off Status	Indicates the status of the mode scheduler function. Logic true if enabled (scheduler). Logic false if disabled (manual).
Various Alarms	Logic true condition indicates the associated alarm is occurring. Logic false if it is not occurring.
AUI Watchdog Status	Must be configured as Remote Output 1. Indicates that a watchdog reset is occurring, due to an error in communication between the Controller and the single-board computer.
Preset Status	Indicates that the associated user-named mode is currently active.
Max Power Lockout Status	Indicates that a maximum power lockout limit (1 to 8) has been selected..Logic true if the lockout has been selected. Logic false if the lockout has not been selected.
Remote Input	Mimics the logic of the associated remote input selection. Example: If Remote Output 5 is set to Remote Input, it will mimic the logic received on remote input pin 5. This is typically used for debugging remote inputs.

Table 8.4: Remote Outputs - Remote Interface PWB Circuits

Remote Output	Output Terminal	Status LED	Shorting Jumper
1	J3-8	DS1	E1
2	J3-7	DS2	E2
3	J3-6	DS3	E3
4	J3-4	DS4	E4
5	J3-3	DS5	E5
6	J3-2	DS6	E6
7	J4-8	DS7	E7
8	J4-7	DS8	E8
9	J4-6	DS9	E9
10	J4-4	DS10	E10
11	J4-3	DS11	E11
12	J5-8	DS12	E12
13	J5-7	DS13	E13
14	J5-6	DS14	E14
15	J5-4	DS15	E15
16	J5-3	DS16	E16

Note: Factory Default Channel and Control are the same for all 16 Remote Outputs. Channel is "Remote Input" and Control is "Output Low When Input Active".

ANALOG OUTPUTS

The transmitter provides sample signals that let you monitor transmitter performance. The sources of these analog outputs are pre-defined and configured at Nautel. See [Table 8.5](#) for a list of these pre-defined outputs, their descriptions and their associated output terminals on the remote interface PWB. The outputs are op-amp buffered outputs from an analog-to-digital converter (ADC). The dc voltage of each output is between 0 to 6 V, and varies within the real limits of the parameter being monitored. The monitoring circuit's impedance for each analog output must be greater than 1,000 ohms.

In addition to the four pre-defined analog outputs, a true RF sample of the RF output voltage waveform is available for external monitoring.

ANALOG OUTPUT CONNECTIONS

Analog outputs 1 through 4 connect to terminals of connector J6 on the remote interface PWB (A11A4). See [Table 8.5](#) to determine the output terminal associated with each analog output.

Table 8.5: Factory Defined Analog Outputs

Analog Output	Description	Output Terminal
1. Forward Power	Reports a sample of the transmitter's forward power level. This dc voltage is a pure square law function and will be 6 V when the forward power is 100 kW	J6-4
2. Reflected Power	Reports a sample of the transmitter's reflected power level. This dc voltage is a pure square law function and will be full-scale (6 V) when the reflected power is 16 kW.	J6-3
3. B+ Voltage	Reports a sample of the control cabinet's B+ dc voltage level. This dc voltage is a linear function and will be full-scale (6 V) when the B+ voltage in the control cabinet is 400 V.	J6-2
4. Dc Current	Reports a sample of the transmitter's dc current level. This dc voltage is a linear function and will be full-scale (6 V) when the dc current is 500 A.	J6-1

WEB BASED CONTROL

An Ethernet port is available on the SBC's motherboard (A1U1) on the back of the control cabinet's front door. This port allows a user with proper authentication to remotely control and interrogate the NX100's operational status. Most functionality available on the front panel AUI is available remotely, provided the user has been granted proper authorization (refer to the NX100 *Operations and Maintenance Manual* for details on setting user permissions). Nautel recommends you use shielded Cat5 cable or better to make this connection.

REMOTE ACCESS

The only access to the AUI is through the **LAN** connector on the control/interface PWB (A4).

For security purposes, Nautel recommends you place your transmitter behind a router acting as a firewall. To allow remote AUI access to a transmitter behind a firewall, the firewall must allow TCP traffic through the following ports:

- TCP port 80: required to allow the web browser operating on the remote computer to access the web server operating on the transmitter.
- TCP port 3501: used for regular AUI-to-transmitter communication. Also used to perform a security check to allow the remote web browser to access AUI content from the transmitter's web server.
- TCP ports 161 and 162: Used for SNMP Agents and Traps, respectively.

For security purposes, Nautel recommends you block the following port:

- TCP port 22: block during normal operation; when required, may be used to allow Secure Shell (SSH) programs such as PuTTY, etc. to access the transmitter.

Once your transmitter is isolated behind a firewall, there are a variety of standard network management techniques that can be used to establish a connection, including routing tables and a virtual private network (VPN).

Detailed information about network management is beyond the scope of this manual. Selecting a specific technique may depend on your existing network configuration. Nautel recommends that the planning, implementation and ongoing support of a network that includes a transmitter be performed by a team that includes at least one member with suitable knowledge of network management.

NOTE: If you have more than one transmitter on the same LAN, you will need to use port forwarding to allow access to individual transmitters on the network.

SNMP CONTROL/MONITORING

SNMP (Simple Network Management Protocol) is a request-response protocol where the client and agent communicate using binary packets. For Nautel transmitters, SNMP is used to communicate transmitter control commands (e.g., RF on/off, main exciter, active preset, power adjustments, etc.) as well as monitor data such as alarm states and meter values. Although there are three different versions of the protocol in widespread use (SNMPv1, SNMPv2c and SNMPv3), Nautel only supports SNMPv1.

Nautel provides the central software component, the SNMP agent, which is a program that runs on the transmitter. The SNMP agent interacts with SNMP client software applications, which range from simple MIB browser applications like the free one provided by iReasoning to customized solutions such as those provided by Burk. Nautel does not provide SNMP client software.

Access to SNMP control/monitoring is through the **ETHERNET/USB** connector (J3A) on the control/interface PWB (A4). When you log into the remote AUI, you can access the **User Settings -> SNMP Configuration** page to set the SNMP Agent Port number, Read Community and Write Community passwords and SNMP Trap information.

If you are planning to use SNMP, contact Nautel to obtain MIB files for your client software.

MIB files are available through Nautel's FTP site: ftp://www3.nautel.com/SNMP_MIBs/

EMAIL SERVER

The transmitter's remote AUI allows you to configure an email notification feature, which can initiate emails to specified users when specific alarm or status conditions occur (refer to the NX100 *Operations and Maintenance Manual* for details).

The NX100 supports email servers that are unsecure and secure; requiring authentication (user name/password) as well as encryption. Consult with your network administrator for more details.

NAUTEL PHONE HOME

Phone Home is a system developed by Nautel that takes advantage of the vast amount of data collected by Nautel transmitters by proactively sending information to Nautel via the internet once a user enables Phone Home on their transmitter.

This data includes logs, alarms and meter readings which are then stored in a database and can be analyzed by Nautel Customer Service if an alarm is reported by the transmitter. Since all data is pushed out to Nautel by the transmitter, there is no need to reconfigure your firewall and potentially compromise your transmitters security. All data transfers are one way.

Nautel transmitters are intelligent, collecting data on nearly every aspect affecting your transmitter's performance. When this data is used by Nautel Customer Service staff for diagnostic purposes it cuts down on repair time and gets you back on air faster.

Nautel Customer Service technicians can use Phone Home to analyze data in real time, even accessing the live AUI, or to view the state of a customer's transmitter at any time leading up to a fault.

This unique diagnostic approach allows Nautel support staff to review the events leading up to and during an alarm occurrence, giving customer service technicians valuable insight into how your transmitter is behaving before, during and after an alarm and how this behavior may be related to the alarm event.

If you are planning to participate in the Nautel Phone Home feature, no pre-installation actions are required. After successfully installing your NX100 and connecting to the remote AUI, navigate to the **User Settings -> Nautel Phone Home** page and enter your serial number and email (optional). Nautel will begin to monitor your transmitter's performance.

SECTION 9: PARTS AND TOOLS

This section describes parts associated with the NX100 transmitter, and tools needed during installation and routine operation. Topics include:

- [Parts supplied by Nautel](#)
- [Parts not supplied by Nautel - see page 9-2](#)
- [Parts ordering - see page 9-2](#)
- [Module replacement program - see page 9-2](#)
- [Tools for installation - see page 9-3](#)

CONTACTING NAUTEL

You can reach Nautel to order parts or for technical assistance at:

Nautel Limited

10089 Peggy's Cove Road
Hackett's Cove, NS Canada B3Z 3J4
Phone: +1.877.628.8353 (Canada/US)
+1.902.823.5100 (International)

Fax: +1.902.823.3183

Email: support@nautel.com

Web: www.nautel.com

PARTS SUPPLIED BY NAUTEL

ANCILLARY PARTS KIT

An ancillary parts kit is shipped with the NX100. This kit contains hardware needed during the installation process. The kit includes toroids, spare fuses, screws and other miscellaneous hardware.

DOCUMENTATION

See “NX100 transmitter manuals” on page xii.

PARTS NOT SUPPLIED BY NAUTEL

Some parts and materials required to complete installation are not supplied by Nautel. The parts you need vary with the installation requirements. The list of parts you normally provide yourself during installation include:

- A suitable 50 Ω RF output coaxial cable, terminated by the proper connector, complete with center male connector at the transmitter end.
 - All external control and monitor wiring, including the associated terminating devices, conduit and conduit clamps.
 - All electrical power cables, including conduit, terminating devices, and conduit clamps.
 - A plastic sheet (or suitable equivalent), used to cover the top of the transmitter during installation to prevent debris and hardware from falling into the transmitter.
-

PARTS ORDERING

You can order replacement parts from your Nautel sales agent, or directly from Nautel through the Nautel website.

MODULE REPLACEMENT PROGRAM

Nautel offers a module replacement program for customers who require expedited servicing and replacement of faulty modules. The module replacement program provides immediate replacement of failed modules with refurbished modules.

- The replacement module is shipped to the customer as soon as the customer reports the failure. The customer then returns the failed module to Nautel using the same shipping package.
-

TOOLS FOR INSTALLATION

The tools you need during transmitter installation include the following:

- Digital voltmeter
- Philips screwdrivers, sizes #1 and #2
- Pliers
- Wire cutters
- Slot screwdriver, 5 mm (3/16 inch)
- Metric and Imperial socket set up to 24 mm (15/16 inch)
- Metric and Imperial wrench set up to 25 mm (1 inch)
- Feeler gauge (to measure spark gap)
- Torque wrench (capable of up to 275 in-lbs or 31 N-m)

SECTION 10: PRE-INSTALLATION ASSISTANCE

Nautel provides a number of support options to help you during pre-installation planning and preparation:

- [Pre-installation consulting](#)
- [Installation and commissioning service](#)
- [Online documentation - see page 10-2](#)
- [On-site support - see page 10-3](#)
- [Training - see page 10-3](#)
- [Extended warranties - see page 10-4](#)

PRE-INSTALLATION CONSULTING

Nautel field support specialists are available to answer questions and work with you to ensure that your site will be ready for the installation of your NX100 transmitter. For support, contact Nautel Customer Service and request assistance (see [“On-site support” on page 10-3](#)).

INSTALLATION AND COMMISSIONING SERVICE

Nautel offers an installation and commissioning service to customers who want assistance with configuring and commissioning a new Nautel transmitter. After the customer completes the transmitter assembly and installation, Nautel technical personnel will spend up to three days on-site to help make the ac power, RF and remote connections, and to assist with the configuration and testing of Nautel equipment.

The customer is responsible for ensuring that the following stages of installation have been completed, prior to the arrival of Nautel personnel:

- Ac power wiring for the transmitter has been installed and connected at the breaker panel or the building's service entrance.
If local electrical codes allow Nautel personnel to connect the transmitter to the ac supply, using the customer's cable, that task is included in this service. Otherwise, the customer must ensure that an approved electrician is present for this task.

- The customer has prepared the RF coaxial cable – used to connect the transmitter to the antenna – and installed the required connector. The customer has also installed the RF coaxial cable in place and connected it to the antenna, while leaving the transmitter end of the cable unconnected.
- Where required, all remote control and monitoring cables have been installed and connected to the station equipment (e.g., modulation monitor, frequency monitor, and power meter).
- The site has been made ready for the equipment, and adequate protection against lightning and lightning-induced transients has been provided.
- The transmitter has been unpacked, closely checked for any damage caused by shipping, and then assembled.
- The following test equipment has been made available at the site:
 - Two-channel oscilloscope (with probes)
 - Audio signal generator
 - Distortion analyzer
 - Modulation monitor
 - Frequency counter
 - 50 Ω test load (rated for 150% of carrier power, VSWR less than 1.1:1)

Nautel’s service representative takes full responsibility for commissioning the transmitter, validating all external interfaces (i.e., the ac supply, RF output, remote control and monitoring equipment) and checking out the equipment prior to activation. The service representative turns on the transmitter, performs all adjustments and set-up procedures, and carries out *proof of performance* tests at the site. These tests ensure that the transmitter is operating normally in compliance with its specifications. The service representative also provides a demonstration and a short explanation of the operation of the transmitter. Finally, the customer signs an *Acceptance of Installation Certificate* that provides feedback to Nautel regarding the commissioning service.

ONLINE DOCUMENTATION

Nautel provides documentation online to customers, letting you familiarize yourself with specifications, operation, maintenance and troubleshooting prior to the delivery of your equipment. See [“Nautel website / Online resources”](#) on page xii.

ON-SITE SUPPORT

If you require on-site assistance, Nautel's field support specialists can help you prepare your site, and ensure that your NX100 transmitter installation can proceed as quickly as possible. For more information about onsite support, including scheduling and pricing, contact Nautel Customer Service:

- Telephone: +1.902.823.5100
- Fax: +1.902.823.3183
- Email: support@nautel.com

After business hours (Atlantic time or Eastern time in North America), requests sent by fax or email will be acknowledged within one working day.

TRAINING

Nautel's SBE-certified broadcast training programs satisfy your day-to-day knowledge requirements. Students participating in Nautel's broadcast transmitter or RF basics training programs earn one SBE credit for each completed day of training. Nautel's comprehensive selection of training programs will help a customer's staff develop valuable skill sets, reduce downtime, and make the most of the customer's technology investment.

Nautel training programs are made up of individual modules that can be *mixed and matched* to meet the customer's specific training needs. All Nautel training courses are available at the Nautel Training Center. Training can also be provided at the customer's facility, for training the customer's technical staff on the customer's transmitter.

All Nautel training courses combine classroom and hands-on laboratory work to ensure a balanced learning experience. Many of our classes also include diagnostic lab exercises.

Nautel training courses feature:

- Limited class sizes to ensure maximum student participation and access to equipment
 - Emphasis on need-to-know, day-to-day knowledge
 - Labs that focus on the tasks most often performed at the transmitter site.
-

NX SERIES ON-SITE OR FACTORY TRAINING

This includes product overview, site and pre-installation, theory of operation, testing and adjustments, operating instructions, system-level troubleshooting, component-level troubleshooting, component parts lists, and wiring route sheets.

EXTENDED WARRANTIES

Nautel's standard four-year warranty provides excellent coverage and satisfies most customers' needs. However, if you want extended coverage, Nautel offers one- and two-year Extended Warranty Plans to cover electrical and mechanical repairs or replacements for all Nautel equipment.

COVERAGE

The Extended Warranty Plan includes:

- A module exchange program for many common modules and circuit boards (North America only)
- Toll-free hotline (North America only)
- Necessary labor performed by Nautel authorized personnel to repair the product to meet factory specifications
- Necessary components
- Modifications to correct performance problems
- Return shipping.

DETAILS

Extended Warranty Plans must be purchased prior to the expiration of original four-year warranty.

One-year Extended Warranty Plans add an additional year (12 months) of coverage after the end of the customer's standard four-year warranty. The two-year plan adds an additional two years (24 months).

Only repairs done at Nautel's facilities or by Nautel authorized personnel will be covered by the Extended Warranty Plans.

You must ship faulty products back to Nautel, prepaid, and in the original package or in a package that provides equivalent protection.

Nautel can choose to repair or replace equipment.

PURCHASING A ONE- OR TWO-YEAR EXTENDED WARRANTY PLAN

If the transmitter is still covered by its original four-year warranty period, you can contact Nautel by telephone, fax, mail, or email with the model number, serial number and date of purchase.

Once you purchase a Nautel Extended Warranty Plan, you receive an extended warranty plan certificate, plan number, and a toll-free number (North America only) to call for any service-related issues.

USING THE EXTENDED WARRANTY PLAN

Contact Nautel's Canadian or U.S. service facility by phone, fax, or email as soon as a problem occurs. The following will be required when contacting Nautel:

- Extended warranty plan number
- Product model number
- Serial number
- Brief description of the problem

If Nautel's service technicians are unable to solve the problem over the telephone, Nautel will give you an RMA number. You then return the module or circuit board to a Nautel service facility, so that Nautel can provide a replacement. *Do not ship a component back to Nautel until you have an RMA number.*

SECTION 11: LIST OF TERMS

This section defines some of the terms that are used in Nautel documentation.

ADC. Analog to Digital Converter.

AES-EBU. Audio Engineering Society/European Broadcasting Union (AES/EBU) is the name of a digital audio transfer standard. The AES/EBU digital interface is usually implemented using 3-pin XLR connectors (the same type connector used in professional microphones). One cable carries both left and right-channel audio data to the receiving device.

B+. The high voltage dc generated by the transmitter's ac power supply for use within the transmitter. The B+ voltage is used to supply the transmitter's modulators and other transmitter circuitry.

CUTBACK. A reduction in RF output power, caused by a total power limit fault or the occurrence of three shutbacks within a five second period.

DAC. Digital to Analog Converter.

DAM. Dynamic Amplitude Modulation.

DCC. Dynamic Carrier Control.

DRM. Digital Radio Mondiale. A set of digital audio broadcasting technologies designed to work existing AM radio channels.

DSP. Digital Signal Processing.

FPGA. Field Programmable Gate Array.

HD RADIO. HD Radio is another term for In Band On Channel (IBOC) technology. HD Radio is a trademark of iBiquity Digital Corporation.

IBOC. Nautel In-Band-On-Channel technology provides high quality digital audio over existing AM radio channels.

IPM. Incidental Phase Modulation

LATCHING ALARM. An alarm that, while active, keeps the transmitter in an 'RF inhibited' state. This type of alarm (e.g., High SWR Shutdown) require a reset - locally or remotely - to attempt to restore transmitter operation.

NE IBOC. Nautel's In-Band-On-Channel signal generator. See IBOC. Required for NX series IBOC installations.

PDM. Pulse Duration Modulation.

PRESET. A setting that controls power level, active exciter, and power scheduler status on a time-of-day and date basis. Exciters can be configured on a preset for a specific operating mode (for example, Exciter A - conventional AM, and Exciter B - IBOC). The NX100 allows you to pre-program multiple presets.

SHUTBACK. A complete loss of RF output power, caused by any one of a variety of faults, including high VSWR, low B+ voltage, high RF current, RF drive failure, external interlock or spark gap.

SURGE PROTECTION BOARD. An electrical panel that protects equipment from electrical surges in the ac power supply, antenna or site ground caused by lightning strikes.

VSWR. Voltage standing wave ratio. This is an expression of the ratio of forward voltage to reverse voltage on the feedline and antenna system. An ideal VSWR of 1:1 provides maximum transmitter-antenna efficiency.

NX100 PRE-INSTALLATION MANUAL

Document: NHB-NX100-PRE

Issue: 3.2 2017-03-31

Nautel Limited

10089 Peggy's Cove Road
Hackett's Cove, NS Canada B3Z 3J4

Toll Free: +1.877.6NAUTEL (662.8835)
(Canada & USA only) or

Phone: +1.902.823.3900 or

Fax: +1.902.823.3183

Nautel Inc.

201 Target Industrial Circle
Bangor, Maine USA 04401

Phone: +1.207.947.8200

Fax: +1.207.947.3693

Customer Service (24-hour support)

+1.877.628.8353 (Canada & USA only)

+1.902.823.5100 (International)

Email: support@nautel.com

Web: www.nautel.com

© Copyright 2017 NAUTEL. All rights reserved.

